


VALVE BOX ADJUSTMENT DETAILS



DETAIL FOR SETTING VALVE BOX

* NOTE: THIS MAY REQUIRE ADDING PVC PIPE WHEN ADJUSTING VALVE BOX TO PAVING GRADE. IF ADDITIONAL PIPE IS REQUIRED, USE BELL SECTION WITH GASKET AND SET BELL DOWN OVER EXISTING PIPE RISER. A GASKETTED SELF-CENTERING COLLAR MAY BE USED IN LIEU OF THE BELL SECTION. ANY ADDITIONAL PVC PIPE REQUIRED SHALL BE SUBSIDIARY TO ADJUSTING THE VALVE BOXES.